



LG G2 mini LTE Battery Replacement

The battery on this device may weaken over time and need to be replaced. This guide will show you how to properly take the old battery out and place a new battery in it's place.

Written By: Aung Myin Thu Mayet






PARTS:

- [LG G2 mini LTE Battery](#) (1)
-

Step 1 — Removing The Cover



- Remove the back cover by placing your fingernail in the crease between the cover and the charging port.
- Pry upward and the cover should pop off easily.

Step 2 — Removing The Battery



- Remove the battery from the battery bay by prying with your finger at the groove on the lower end of the battery bay.
- Now you are able to replace the battery with a new one.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-28 10:52:21 PM.